












SW 8523 - F/Q/K









WARNING!!

- Remove hardware from box and sort by size.
- Please check to see that hardware and parts are present prior start of assembly.
- Please follow attached instruction in the same sequence numbered to ensure fast and easy assembly.
- Do not use this bed if any part is broken, torn or missing.
- The assembly of this product requires two people.
- Do not use any power tools as this may damage the frame and will invalidate any claim.

PART LIST

P1		Headboard Curve Rail =	2pcs
P2		Headboard Rail =	2pcs
P3		Headboard Bottom Rail =	1pc
P4		Footboard Rail =	1pc
P5		Side Rail =	2 pcs
P6		Headboard Stand =	2pcs
P7		Corner Block =	4pcs
P8		Post =	4pcs
P9		Center Rail =	1pc
P10		Bed Slats =	14pcs
P11		Support Leg =	2pcs

HARDWARE LIST

A		M6 X 50MM JCBC =	14pcs
B		M6 X 30MM JCBC =	24pcs
C		ALLEN KEY M4 WITH BALL =	1pc
D		M10 X 30MM WOOD DOWEL =	8pcs
E		HEX NUT 5/16 =	8pcs
F		WRENCH =	1pc
G		M4 X 25MM SCREW =	14pcs
H		ADJUSTER =	2pcs

Attach the side rail (P5) to the headboard bottom rail (P3) and footboard rail (P4). You will need to use hardware:

A = 8pcs
C = 1pc
D = 8pcs

Attach the post (P8) to the corner block (P7) using hardware:

E = 8pcs
F = 1pc

After that, attach the corner block (P7) to the headboard bottom rail (P3), footboard rail (P4) and side rail (P5). You will need to use hardware:

B = 16pcs
C = 1pc

Attach the headboard stand (P6) to the headboard bottom rail (P3). After that, attach the headboard curve rail (P1) and headboard rail (P2) to the headboard stand (P6) using hardware:

A = 4pcs
B = 8pcs
C = 1pc

Fix the adjuster (H) to the support leg (P11) using hardware:

H = 2pcs

Attach the support leg (P11) to the center rail (P9) using hardware:

A = 2pcs
C = 1pc

Attach the center rail (P9) to the headboard bottom rail (P3) and footboard rail (P4) using hardware:

G = 2pcs

Lay the bed slats (P10) between the side rail (P5) using hardware:

G = 12pcs

****Apply pressure with your knee to the side rail whilst attaching the slats to ensure that the slats are flush against the inside of side rail****

